


- 4 DISPEACEMENT CALCULATION CIRCUIT
- 5. MAGNETIC BEARING DRIVE CIRCUIT
- 6 INVERTER





22 DISPLACEMENT DETECTION CIRCUIT

23 MAGNETIC BEARING

24 MoTOR

25 REVOLUTION NUMBER SENSOR

11 VOICE OUTPUT PORTION

14 COUNTER

16 MEMORY

10 DISPLAY PORTION

ŝ

